



Assemble anchor bolts to template as shown above.
 Install bottom of template flush with top of finished grade.
 Note: Template must be installed level in both directions.

Typical Anchor Bolt Installation			
STAMP		STRUCTURA 19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com	
		Spar Poles	
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	6/23/2016	Spar - Bolt Down.idw