



SECTION A-A

Place 3/4" template on top of 3/8" template for proper thickness. Assemble anchor bolts to template as shown above. Install bottom of template flush with top of finished grade.

Note: Template must be installed level in both directions!

Typical Anchor Bolt Installation			
STAMP	STRUCTURA		
	19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
TVE Poles			
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	5/26/2016	TVE - Bolt Down.idw