



Use baseplate template to install anchor bolts. Slope concrete away from baseplate. After concrete has set, remove base accent panels from bollard and set aside. Remove template and set bollard on top of anchor bolts. Tighten flange nuts until bollard is secure. Reattached accent panels.

Typical Anchor Bolt Installation			
STAMP	STRUCTURA		
	19922 W. 162nd Street Olathe, KS 66062		phone 913.390.8787 projects@structura.com
Duo Bollard C			
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	9/28/2016	DBC - Anchor Bolt.idw