



Use baseplate template to install anchor bolts. Keep template 3/8" off the top of the concrete. Slope concrete away from baseplate. After concrete has set, remove template and place actual baseplate on anchoring bolts making sure to adjust hex nuts to level it. Set bollard on top of baseplate and secure with 1/4"-20 security flat head (T30 security bit required).

Ensure concrete is cured before installing bollard.

Typical Mac Anchor Bolt Installation			
Template: 91252			
STAMP	STRUCTURA		
	19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
Mac XL Columns			
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1		10/31/2023	Mac - Anchor Bolt.idw