



Use baseplate template to install anchor bolts. Keep template 3/8" off the top of the concrete. Slope concrete away from baseplate. After concrete has set, remove template and place actual baseplate on anchoring bolts making sure to adjust flange nuts to level it. Set bollard up right and tighten tension rods until secure.

Typical MAC Anchor Bolt Installation			
Template: 91252			
STAMP	STRUCTURA		
	19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
Mac Bollards			
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		4/5/2018	Mac - Anchor Bolt.idw