



Attach screw-in foundation to 5-1/4" Kelly Bar with (6) 1/2" Grade 5 bolts. Install screw-in foundation into ground foundation. Ensure levelness of screw-in foundation during and after installation. Remove Kelly Bar from foundation. Removed baseplate from bollard by removing (4) 1/4"-20 flat head screws. Secure bollard baseplate to foundation with 3/8"-16 carriage bolt and flange nut. Set bollard onto baseplate and resecure flat head screws.

Typical Zora Screw-In Foundation			
STAMP	STRUCTURA 19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
	Zora Bollard		
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		10/23/2019	Zora - SCW.idw