



Assemble anchor bolts to template as shown above. Install anchors into foundation maintaining access to leveling nut below template. There is 3 5/8" of clearance under the base cover.

Template must be installed level in both directions.

Mode Traditional Anchor Bolt Installation			
STAMP	STRUCTURA		
	9635 Widmer Rd. Lenexa, KS 66215		phone 913.390.8787 service@structura.com
PROJECT NAME		PROJECT LOCATION	
SHEET NUMBER 1 of 1	REVISION Issue	DATE 5/7/2025	DRAWING 1 Mode - Traditional.idw