



SECTION A-A

Assemble anchor bolts to template as shown above.  
 Install bottom of template flush with top of finished grade.  
 Note: Template must be installed level in both directions!

Typical Anchor Bolt Installation			
STAMP		<b>STRUCTURA</b>	
		19922 W. 162nd Street    phone 913.390.8787 Olathe, KS 66062    projects@structura.com	
Tandem Poles			
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	6/23/2016	Tandem Bolt Down.idw