


Use baseplate template to install anchor bolts as shown. Use supplied leveling nuts to ensure that the template is level in both directions. Slope concrete away from baseplate. After concrete has set, remove template from anchor installation and set bollard on top or anchor bolts. Carefully remove bollard accent panel to expose installation handhole. Tighten 3/8"-16 hex nuts until bollard is secure.

Typical Elm Bollard Anchor Bolt installation			
STAMP			
	9635 Widmer Rd. phone 913.390.8787 Lenexa, KS 66215 projects@structura.com		
Project Name		Project Location	
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		11/15/2023	Elm BL - Anchor Bolt.idw