Pike

Interior Pendant Installation Instructions



Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

Tools Required

7/64" Allen wrench Phillips head screw driver Wiring tools and connectors

Installation

Step 1: Turn off power to location.

Step 2: Slide junction box cover and junction box mounting plate onto fabric power cord. Mounting only fits on a 4" octagonal junction box (supplied by others) with opening flush to ceiling surface.

Step 3: Place wire clamp onto power cord at desired length and secure by tightening (2) #6-32 socket cap screws. If power cord needs to be trimmed, tightly wrap electrical tape around cord before cutting to prevent fabric from fraying.

Step 4: Make wire connection inside junction box.

Step 5: Secure junction box mounting to junction box using screws supplied with junction box. Slide junction box cover up until held by magnets attached to mounting plate

Step 6: Turn power back on to location.









