


FOUNDATION DESIGN
BY OTHERS

Use baseplate template to install anchor bolts as shown. Slope concrete away from baseplate. After concrete has set, remove baseplate from bollard by removing four screws. Replace template with bollard baseplate. Tighten 3/8"-16 flat head bolt until baseplate is secure. Set bollard onto baseplate and secure.

Typical Lineal Bollard Anchor Bolt Installation			
Template: 95431			
STAMP			
	19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
Lineal Bollard			
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		6/18/2019	LBL - Bolt Down.idw