


Attach u-bolts to template as shown. Do not adjust coupling nuts. Push template into concrete to install anchor bolts. Slope concrete away from baseplate. After concrete has set, remove baseplate from bollard. Replace template with bollard baseplate. Tighten 3/8"-16 flat head bolt until baseplate is secure. Set bollard onto baseplate and secure.

Note: The template MUST be installed level! Use washers/shims under the baseplate if adjustment is needed after concrete has set.

Typical Lineal Bollard Anchor Bolt Installation			
Template: 95431			
STAMP			
	9635 Widmer Rd. phone 913.390.8787 Lenexa, KS 66215 projects@structura.com		
Project Name		Project Location	
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1	A	2/2/2022	LBL - Bolt Down.idw