



Assemble anchor bolts to template as shown above.
 Install bottom of template flush with top of finished grade.
 Note: Template must be installed level in both directions!

Typical Toka Anchor Bolt Installation			
Template: 96019			
STAMP	STRUCTURA		
	19922 W. 162nd Street Olathe, KS 66062		phone 913.390.8787 projects@structura.com
Toka Poles			
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		3/19/2020	Toka - Bolt Down.idw