



Use baseplate template to install anchor bolts as shown. Use supplied leveling nuts to ensure that the template is level in both directions. Slope concrete away from baseplate. After concrete has set, remove template from anchor installation and set bollard on top or anchor bolts. Carefully remove bollard accent panel to expose installation handhole. Tighten 3/8"-16 hex nuts until bollard is secure.

Typical Beam Bollard Anchor Bolt installation			
STAMP			
	9635 Widmer Rd. Lenexa, KS 66215		phone 913.390.8787 projects@structura.com
Beam Bollard			
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		8/10/2021	Beam BL - Anchor Bolt.idw