

Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

Tools Required

2.5mm Allen wrench
Wiring tools and connectors

Installation

Step 1: Turn off power to location.

Step 2: Ensure drilled mounting pattern matches the bolt pattern as shown in Figure A and secure mounting plate with #8 hardware (by others).

Step 3: Place luminaire body over mounting plate with mounting tabs aligning to recesses in luminaire body as shown in Figure B and C.

Step 4: Secure luminaire body to mounting plate by inserting supplied M5 set screws into threaded holes on left and right side of luminaire body.

Step 5: Connect luminaire wiring to incoming power and dimming (if applicable) as shown in Figure E diagram.

Step 6: Turn power on to location.

