



Use baseplate template to install anchor bolts as shown. Slope concrete away from baseplate. After concrete has set, remove baseplate from bollard by removing (4) 1/4"-20 flat head screws. Replace template with bollard baseplate. Tighten 3/8"-16 hex nuts until baseplate is secure. Set bollard onto baseplate and secure screws.

Typical Zora Anchor Bolt Installation			
STAMP	STRUCTURA 19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
	Zora Bollard		
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		10/23/2019	Zora - Anchor Bolt.idw