


Place template at desired location over conduit with arrow pointing forward. Use template as a drill guide to install concrete anchors. After anchors are in place, remove template and place pathway light in location. Tighten concrete anchors until secured.

Typical Anchor Installation			
STAMP		 19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com	
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	8/17/2016	Vivat - Anchor Bolt.idw