



Use baseplate template to install anchor bolts as shown. Use supplied leveling nuts to ensure that the template is level in both directions. Slope concrete away from baseplate. After concrete has set, remove template from anchor installation and set bollard on top or anchor bolts. Carefully remove bollard accent panel to expose installation handhole. Tighten 3/8"-16 hex nuts until bollard is secure.

Typical Ortho LED Bollard Anchor Bolt installation

STAMP	STRUCTURA		
	9635 Widmer Rd. Lenexa, KS 66215	phone 913.390.8787	projects@structura.com
Ortho LED Bollard			
SHEET NUMBER 1 of 1	REVISION	DATE 12/6/2022	DRAWING Ortho BL - Anchor Bolt.idw