



Assemble anchor bolts to template as shown in the drawing. Anchor bolts must be installed vertically straight. Level template in all directions and leave until foundation has cured. After foundation has cured, remove template and secure pole to anchor bolts.

Traditional Elm Anchor Bolt Installation			
STAMP			
	9635 Widmer Rd. phone 913.390.8787 Lenexa, KS 66215 projects@structura.com		
Project Name		Project Location	
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		4/23/2021	Elm - Anchor Bolt.idw