



Use baseplate template to install anchor bolts. Bring anchor bolts up at least 2.25" above template. Slope concrete away from baseplate. After concrete has set, remove base accent panels from column and set aside. Loosen base bolts inside base compartment to release baseplate. Remove template and set actual baseplate on anchor bolts. Tighten flange nuts until baseplate is secure. Set column on top of baseplate and resecure base bolts. Reattached accent panels.

Typical Anchor Bolt Installation			
STAMP	STRUCTURA 19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
	Duo Light Column		
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	6/23/2016	DLC - Anchors.idw