



Use baseplate to install anchor bolts.  
 Keep baseplate 1/4" off the top of the concrete.  
 Slope concrete away from baseplate.

Note: drawing not too scale

Typical Anchor Bolt Installation			
STAMP			
	19922 W. 162nd Street    phone 913.390.8787 Olathe, KS 66062    projects@structura.com		
Mac XL Columns			
SHEET NUMBER	REVISED	DATE	DRAWING
1 of 1	#	6/23/2016	Mac XL - Anchors.idw