



Use baseplate template to install anchor bolts as shown. Slope concrete away from baseplate. After concrete has set, remove baseplate from bollard by removing four screws. Replace template with bollard baseplate. Tighten 3/8"-16 hex nuts until baseplate is secure. Set bollard onto baseplate and secure screws.

Typical Spar Bollard LED Anchor Bolt Installation			
STAMP	STRUCTURA		
	19922 W. 162nd Street phone 913.390.8787 Olathe, KS 66062 projects@structura.com		
Spar Bollard LED			
SHEET NUMBER	REVISION	DATE	DRAWING
1 of 1		1/7/2019	SBL-LED - Anchor Bolt.idw