



Attach screw-in foundation to 5-1/4" Kelly Bar with (6) 1/2" Grade 5 bolts. Install screw-in foundation into ground foundation. Ensure levelness of screw-in foundation during and after installation. Remove Kelly Bar from foundation. Remove baseplate from bollard by removing (4) 1/4"-20 flat head screws. Secure bollard baseplate to foundation with 3/8"-16 carriage bolt and flange nut. Set bollard onto baseplate and resecure flat head screws.

| Typical Ata Screw-In Foundation | | | |
|---------------------------------|---|------------|--|
| STAMP | STRUCTURA | | |
| | 19922 W. 162nd Street Olathe, KS 66062 | | phone 913.390.8787 projects@structura.com |
| Ata Bollard | | | |
| SHEET NUMBER | REVISION | DATE | DRAWING |
| 1 of 1 | | 10/23/2019 | Ata - SCW.idw |