Stela

Surface Installation Instructions



Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

Tools Required

Phillips head screw driver Wiring tools and connectors

Installation

Step 1: Turn off power to location.



- Step 3: Secure luminaire mounting cap to mounting plate using supplied screws.
- Step 4: Make wire connection in accordance to Figure D and push into junction box.
- Step 5: Screw luminaire into mounting cap until secured.
- Step 6: Turn power back on to location.









