# Pike

#### **Exterior Pendant Installation Instructions**



#### Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

## **Tools Required**

1 1/16" crescent wrench Phillips head screw driver Wiring tools and connectors

### Installation

- Step 1: Turn off power to location.
- Step 2: Screw cordgrip into 4" octagonal junction box cover. Slip power cord through junction box as shown in Figure A.
- Step 3: Adjust power cable to desired length and secure in place by tightening the cordgrip.
- Step 4: Make wire connection inside junction box (supplied by others).
- Step 5: Secure junction box cover and gasket to junction box using screws supplied with junction box.
- Step 6: Turn power back on to location.









