

Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

Tools Required

T30 Security Bit

3/8" Socket Wrench

Wiring tools and connectors

Bollard Installation

Step 1: Remove 1/4-20 machine screws from bottom of bollard and remove the mounting plate as seen in Figure A.

Step 2: Place mounting plate on anchor bolts and place 3/8" washer down and tighten 3/8" hex nut as seen in Figure B.

Step 3: Secure bollard on to mounting plate with the 1/4-20 machine screws used in figure A

Step 4: Connect wires from the solar battery to the fixture module.

Step 5: Secure 1/4-20 machine screws through the bollard and into the fixture module as seen in Figure D.

